

- 1) **Dust mop floor every day with a quality dust mop.**
 - a. Several dust moppings per day may be required during periods of heavy use.
 - b. Dust mops should be cleaned regularly.
 - c. If a dust mop treatment is use, be careful not to overuse the product as the floor may get very slippery. If floor is saturated with dust mop treatment, it may be necessary to scrub floor with Valspar Flooring's WP-15 Waterless Cleaner or tack floor with clean towels with WP-15 Waterless Cleaner.

- 2) **Damp mop floor with a quality wet mop, as needed.**
 - a. Make sure not to flood floor in process.
 - b. The mops should only be slightly damp and change water frequently while removing dirt.
 - c. Never use a cleaning product that will leave any film on surface, which can cause a slippery surface and reduce the gloss of the finish.

- 3) **All entrances should have walk off mats to lessen amount of soil being deposited on floor. Mats should be cleaned often.**

- 4) **Always remember, good maintenance will postpone the need for recoating.**